
USL


SK19276C2 PORTLAND KICHEN CART ASSEMBLY INSTRUCTIONS


Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have came loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, please contact our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.


IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.







HOW TO REMOVE DRAWERS




WHEN REMOVING DRAWERS, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDES.


NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST

AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN

ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM

WITH AT LEAST TWO PEOPLE.






NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY

ARE TIGHT, THE SHOULDER SHOULD BE

AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL



NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

