


# PRODUCT OVERVIEW

## Parts



## Accessories

### Included Accessories



Standard rack (3ea)



Griddle (1ea)




Rear filler (1ea)




Owner's manual (1ea)


### Anti-tip kit




Anti-tip (1ea)



Screws (6ea)




Anchors (6ea)



Template (1ea)


### LP nozzle conversion kit



Cooktop Nozzles (5ea)



Oven Nozzles (2ea)




Installation Guide (1ea)

### EasyClean™ kit



Spray bottle (1ea)



Non-scratch scouring pad (1ea)

### Optional Accessories



Grid



Broiler pan

### NOTE

- Contact LG Customer Service at 1-800-243-0000 (1-888-542-2623 in Canada) if any accessories are missing.
- For your safety and for extended product life, only use authorized components.
- The manufacturer is not responsible for product malfunction or accidents caused by the use of separately purchased, unauthorized components or parts.
- The images in this guide may be different from the actual components and accessories, which are subject to change by the manufacturer without prior notice for product improvement purposes.