## **Tubing Cutters**

## **TUBING CUTTER SELECTION**

Pico Outley		Page No.	Diameter	Material / Diameter				
Pipe Cutter				Steel / Stainless	Copper	Aluminum	Plastic/PVC	
Close Quarters Tubing Cutters	HOSE	3.14	1/4" - 11/8"	•	•	•		
2-in-1 Close Quarters AUTOFEED™ Cutter	Z	3.15	1/4" - 11/8"	•	•	•		
Constant Swing Tubing Cutters		3.15	1/8" - 13/8"	•	•	•		
Enclosed Feed Tubing Cutters		3.16	1/4" - 23/8"	•	•	•		
Quick-Acting Tubing Cutters		3.16	<sup>1</sup> /4" - 6 <sup>5</sup> /8"	•	•	•	•	
Screw Feed Tubing Cutters		3.17	1/8" - 31/8"	•	•	•		
Internal Tubing Cutters	The state of the s	3.17	2-4	•	•	•	•	
Stainless Steel Duty Tubing Cutters	5	3.17	3/16" - 25/8"	•	•	•		
Plastic Pipe Cutters	7	3.19-3.21	1/8" - 17/8"				•	



## **CLOSE QUARTERS TUBING CUTTERS**

- Specifically designed for use in restricted spaces on small diameter, hard and soft copper, aluminum, brass and plastic tubing.
- Rollers include grooves for close-to-flare cuts on models 101, 101J and 118.
- Strong, lightweight slide and wheel housing, and large knurled feed screw knob give easy control of cutting pressure for clean cuts.
- Models 117 and 118 include a self-feeding AUTOFEED® cutter wheel that automatically cuts after tightening the knob only once.
- Models 101, 117 and 118 feature a special knob for easier tightening of the feedscrew.
- Model 101-ML is for multilayer tubing in only.

Catalog Model		Description	Std. Wheel	Capacity		Weight		Std. Pack
No.	lo. No. Description			in.	mm	lb.	kg	olu. Pack
40617	101		E-3469	1/4 - 11/8	6 - 28	1/2	0.23	6
32975	103	Close Quarters Cutter	E-3469	1/8 - 5/8	3 - 16	1/3	0.15	
32985	104		E-3469	<sup>3</sup> /16 - <sup>15</sup> /16	5 - 24			
97787	117	Close Quarters AUTOFEED Cutter	E-3469	<sup>3</sup> /16 - <sup>15</sup> /16	5 - 24			12
86127	118	Close Quarters AUTOFEED® Cutter Only	E-3469	1/4 - 11/8	6 - 28	5/ <sub>8</sub>	0.26	6
32933		Ratchet Handle Only for 101 and 118 Tubing Cutter		-	-	7/8	0.20	NA

Models 117 and 118 include a self-feeding cutter wheel that automatically cuts after tightening the knob only once (AUTOFEED). \*Models 101 and 118 include spare cutter wheel in knob.

(TOOLTIP)

For best cutting results, change the cutter's wheel pin at least once for every two cutter wheel replacements.