


INSTRUCTIONS FOR MODELS


VS-1240 (-E2)
VSR-1240 (-E2)



NEED HELP?

For additional assistance or service please contact:

SPEAKMAN® Company
400 Anchor Mill Road
New Castle, DE 19720

 800-537-2107

 customerservice@speakman.com

 www.speakman.com


92-VS-1240-02

TOOLS AND SUPPLIES

Thread Seal
Tape



Adjustable
Wrench



IMPORTANT



Be sure to read instructions thoroughly before beginning installation. Do not overtighten any connections or damage may occur. This hand shower has an optimal operating range of 20-80 psi.

SAFETY TIPS

Cover your drain to prevent loss of parts.

MAINTENANCE

Periodic cleaning using a mild soap and warm water will help keep your Hand Shower's appearance in its original condition.

For best results, dry immediately with a soft, clean cloth. **DO NOT USE** harsh and/or abrasive cleaners.


On CHROME PLATED HAND SHOWERS, a two (2) part white vinegar, one (1) part water solution can be used to break down excessive mineral deposits on the sprays. Let the hand shower soak in the solution for about ½ hour then rinse thoroughly. Brush off any remaining mineral deposits if necessary.

DO NOT USE the vinegar/water treatment on any finish other than Chrome.


WARRANTY

Additional warranty information can be found at:
www.speakman.com


- 1** Apply Thread Seal Tape to the outlet side of shower arm in a clockwise direction.




- 2** Thread Bracket onto shower arm by turning it in a clockwise direction. Tighten with adjustable wrench.




- 3** Thread Hose End with Label to base of Hand Shower. Hand tighten. Remove label.




- 4** Thread remaining end of hose to the outlet port of Bracket. Hand tighten.




- 5** Place Hand Shower into Bracket. Turn on water supplies and check for leaks.



- 6** Rotate Spray Face to change Spray Settings.



ROUGH IN DIMENSIONS



VS(R)-1240
 Max. Flow Rate: 2.5 gpm (9.5L/min)
 Min. Flow Rate: 2.0 gpm (7.6 L/min) @ 45psi
 FOR USE WITH AUTOMATIC COMPENSATING VALVES RATED AT
 7.6 L/MIN (2.0 GPM) OR LESS.

VS(R)-1240-E2
 Max. Flow Rate: 2.0 gpm (7.6 L/min)
 Min. Flow Rate: 1.5 gpm (5.7 L/min) @ 45psi
 FOR USE WITH AUTOMATIC COMPENSATING VALVES RATED AT
 6.6 L/MIN (1.75 GPM) OR LESS.

REPAIR PARTS

