

WARNING

WARNING -TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS, PLEASE READ THE FOLLOWING PRIOR TO INSTALLING THE FAN:

1. Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer. 2. Before servicing or cleaning unit, switch power off at service panel to prevent power from being switched on accidentally. When the service disconnect cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel. 3. Installation work and electrical wiring must be done by a licensed person(s) in accordance with all applicable codes and standards, including fire-rated construction codes and standards. 4. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent backdraft. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and the local code authorities. 5. When cutting or drilling into wall or ceiling do not damage electrical wiring and other hidden utilities. 6. Ducted fans must always be vented to the outdoors. 7. Unit is acceptable for use over a tub or shower when connected to a GFCI (Ground Fault Circuit Interrupter) protected branch circuit (ceiling installation only). 8. This unit must be grounded. 9. Not for use in kitchens. 10. Install fan at least 2.5 m (8.2 feet) above the floor. 11. To reduce risk of fire and to properly exhaust air, be sure to duct air outside. Do not vent exhaust air into spaces within walls or ceilings or into attics, crawl spaces, or garages. This unit is appropriate for wall installation in a non-wet application. 12. **WARNING:** To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device. 13. The fan must not be installed in a ceiling thermally insulated to a value greater than R40.

CAUTION

1. For general ventilating use only. Do not use to exhaust hazardous or explosive materials and vapors. 2. This product is designed for installation in ceilings up to a 12/12 pitch (45 degree angle). Duct connector must point upward for wall application. 3. To avoid motor bearing damage and noisy and/or unbalanced impellers, keep drywall spray, construction dust, etc. off power unit. 4. Please read specification label on product for further information and requirements.

*This manual in electronic format may be downloaded from our company website or obtained from the dealer.

CLEANING & MAINTENANCE

For quiet and efficient operation, long life, and attractive appearance - lower or remove grille and vacuum interior of unit with the dusting brush attachment.

The motor is permanently lubricated and never needs oiling.

OPERATION

The control box, located inside the fan housing, has three separate adjustments:

- (1) The time delay knob which is adjustable from 5 to 60 minutes and switches the humidity sensor knob.
- (2) The humidity sensor for setting the proper relative humidity level in the room.
- (3) The toggle switch will adjust the upper fan speed setting from 80 to 120 CFM using a 4" duct or 90 to 140 CFM using a 6" duct.

Both 4" and 6" duct adaptors are included.

Times of operation:

- (a) When someone enters then leaves the room.
- (b) When humidity rises above a user-adjustable set point (50-100% Relative Humidity (RH)).

Timer delay knob
Humidity Sensor knob
Toggle switch
Power box
1 2 3
is the position of switch

	1 2 3	1 2 3	1 2 3	1 2 3	1 2 3	1 2 3	1 2 3	
Airflow (CFM)	80	90	110	120	90	110	120	140
Duct Diameter (inches)	4"	4"	4"	4"	6"	6"	6"	6"

Factory setting: 110CFM () with 6" duct
HVI Certified performance based on HVI Procedures 915, 916, and 920.
Other airflow reference performance based on HVI Procedures 915, 916, and 920.

READ AND SAVE THESE INSTRUCTIONS
Installer: Leave this manual with the homeowner.

OPERATION

HUMIDITY SENSOR OPERATION

The humidity-sensing fan uses a sophisticated humidity sensor that responds to: (a) rapid to moderate (user-adjustable) increases in humidity or (b) humidity above a user-adjustable set-point (50%-100% relative humidity). The humidity sensor may occasionally turn the fan ON when environmental conditions change. If the fan continuously responds to changing environmental conditions, "H" (means "humidity") adjustment may be required. This feature is factory-set for 75% relative humidity level at ambient temperature of 77°F.

SENSITIVITY ADJUSTMENT


The "H" has been factory set for most shower applications. If fan is in a tub area or is being used for dampness control, the "H" may need to be increased toward maximum "+". If the control is responding too often to changing environmental conditions, movement toward less "-" "H" may be required.

To adjust the "H":

1. Disconnect power at service entrance.
2. Through the grille, locate the slot marked "H".
3. Carefully rotate the "H" adjustment toward "+" or "-".
4. Turn on power and check operation by turning on the shower or other humidity source until the fan turns on.
5. Repeat above steps if necessary. When the temperature changes, humidity sensor values may deviate.

MOTION SENSOR

Sensing distance will be impacted by the body's own mass i.e., a smaller person will require more remote sensing distance. Turn on the sensor switch and the system begins working. The fan runs continuously at a pre-set level. When you enter the bath area the fan begins working. When you leave the fan remains working until the delay time has passed, and then the fan will shut off.





Installation distance: 2.5m to 3m.

Sensing range is within the cone angle of 90°.

PLAN THE INSTALLATION

1. Do not use in a cooking area.
2. Two ways to connect ductwork to a factory-shipped unit.




ASSEMBLY INSTRUCTIONS

1. Before installation, you need to know:

Screw A		ST4.2*13mm
Screw B		ST4.2*25mm
Hanger bar (short)		7 1/2 in (190mm)
Hanger bar (long)		13 3/8 in (340mm)

Note: Hanger bar (short) only can slide into channel A.




ASSEMBLY INSTRUCTIONS

2. Mount with mounting holes and hanger bar

Slide one hanger bar into the channel on the housing and adjust as needed to fit between framing. Hold housing in place so that the housing contacts the bottom of the joist. Screw housing to joist through the hole A and hole B. Screw the hanger bar onto the other side of joist through the hole (refer to diagram at right). Screw hanger bar to housing with screw A.

Hanger Bar Options

Distance A	Hanger Bar	Channel
13 1/4 in to 15 1/2 in (336mm-394mm)	Hanger bar (short)	Channel A (Fig. 1)
16 1/2 in to 18 7/8 in (419mm-480mm)	Hanger bar (long)	Channel B (Fig. 2)




3. Mount with hanger bars only

Slide hanger bars onto housing and adjust as need to fit between framing. Extend the hanger bars to the width of the framing. Position the fan with the hanger bar tabs wrapped around the bottom edge of the framing, holding the fan in place. Secure hanger bars to framing using one screw on each end of hanger bar (refer to diagram at right). Screw hanger bar to housing with screw A.


Hanger Bar A Option

Distance A	Hanger Bar A
14 in to 23 1/2 in (356mm-597mm)	Hanger bar (short)
21 1/4 in to 23 1/2 in (540mm-597mm)	Hanger bar (long)




4. Mount to I-joist

Slide one hanger bar (long) into channel B on the housing and adjust as needed to fit between framing. Hold housing in place so that the housing contacts the bottom of the joist. Screw housing to joist through hole D and hole C. Screw the hanger bar onto the other side of joist through the hole (refer to diagram at right). Screw hanger bar to housing with screw A.





5. INSTALL ROUND DUCTWORK

Connect the round ductwork (not included) to the damper/duct connector and run the ductwork to a roof or wall cap (not included). Using duct tape (not included), secure all the ductwork connections so that they are air tight. Insulated flexible duct is recommended for the quietest possible installation. A 1 – 3 foot run of rigid duct- followed by insulated flexible duct- will ensure quietest operation.



CONNECT ELECTRICAL WIRING

Run 120 V AC house wiring to the location of the fan. Use only UL-approved connectors (not included) to attach the house wiring to the wiring plate. Refer to the wiring diagram, and connect the wires as shown.




INSTALL GRILLE

Install ceiling material to complete the ceiling construction. Then, cut around the fan housing.


First, insert the sensor plug into the plug base on the power box then install the grille.

To attach the grille assembly to the fan housing, pinch the grille springs on the sides of the grille assembly, and position the grille into the housing with the grille springs in the appropriate slots. Gently push the grille assembly towards the ceiling to secure.



SERVICE PARTS

PART	PART NAME	Qty.
1	Grille Assembly (includes part 2)	1
2	Grille Spring	2
3	Power box	1
4	Motor Plate	1
5	Motor	1
6	Blower Wheel	1
7	Wire Panel / Harness Assembly	1
8	Hanger Bar Kit (long)	3
9	Wiring plate	1
10	Housing	1
11	Hanger Bar Kit (short)	1
12	Damper / Duct Connector	1
13	Motion system	1
a	Nut, Hex Lock	4
b	Washer	4
c	Screw	1
d	Isolator	4
e	Screw	1



* Blower Assembly includes part 6, 5, d, 4, c, b, a. Replacement installation: Remove the screw (part c), then take out the motor plate (part 4) from the housing (part 10) by pushing down the rib in the plate while pulling out on the side of the housing. Replace broken parts.

WARNING: Before replacing, be sure to turn off power at power source.

WARRANTY

This warranty covers all defects in workmanship or materials for:

The mechanical and electrical parts contained in this product for a period of 72 months from the date of purchase. You must keep and be able to provide your original sales receipt as proof of date of purchase. This warranty is covered to the original retail purchaser of this product only. The manufacturer will replace any mechanical or electrical part that proves defective in normal household use for a period of 72 months.

THIS WARRANTY DOES NOT COVER:

- Damages from improper installation.
- Damages from shipping.
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance.
- Damages from service by persons other than a licensed electrician.
- Does not cover any labor or transportation charges related to the repair of this product.

THIS LIMITED WARRANTY IS GIVEN IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The remedy provided in this warranty is exclusive and is granted in lieu of all other remedies. This warranty does not cover incidental or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. Some states do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you. This warranty gives you specific legal rights; you may also have other rights, which vary from state to state.

READ AND SAVE THESE INSTRUCTIONS

Installer: Leave this manual with the homeowner.