

Table III. Copper Roll Groove Specifications

1	2		3	4	5	6	7	8
Nom. Size Inches	Tubing Outside Diameter O.D.		A Gasket Seat A ±0.03	B Groove Width +.03 -.000	C Groove Dia. +.00 -.02	D Groove Depth Ref. ¹	T Min. Allow. Wall Thick.	Max. Allow. Flare Dia.
	Basic	Tolerance						
2"	2.125	±0.002	0.610	0.300	2.029	0.048	DWV	2.220
2½"	2.625	±0.002	0.610	0.300	2.525	0.050	0.065	2.720
3"	3.125	±0.002	0.610	0.300	3.025	0.050	DWV	3.220
4"	4.125	±0.002	0.610	0.300	4.019	0.053	DWV	4.220
5"	5.125	±0.002	0.610	0.300	5.019	0.053	DWV	5.220
6"	6.125	±0.002	0.610	0.300	5.999	0.063	DWV	6.220
8"	8.125	+0.002/-0.004	0.610	0.300	7.959	0.083	DWV	8.220

1. Nominal Groove Depth is provided as a reference dimension. Do not use groove depth to determine groove acceptability.

Troubleshooting

SYMPTOM	POSSIBLE REASONS	SOLUTION
Roll groove too narrow or too wide.	Grooving roll and/or driving shaft worn.	Replace grooving roll and/or drive shaft.
Rolled groove not perpendicular to pipe axis.	Pipe length not straight. Pipe end not square with pipe axis.	Use straight pipe. Cut pipe end square.
Pipe will not track while grooving/Groover will not track on pipe while grooving.	Pipe and drive shaft not parallel. Pipe axis not offset ½ degree from driving roll axis. Driving roll knurl plugged or worn flat. Feedscrew not tight. Turning ratchet wrong direction. Inside of pipe has too much scale. Excessive weld seam. Not applying pressure to pipe. Pipe end not square/deburr. Feedscrew too tight.	Adjust stand to make pipe parallel. Offset pipe ½ degree. Clean or replace drive roll. Tighten feedscrew with ratchet for every revolution as per directions. Turn ratchet in proper direction. Clean inside of pipe. Grind weld seam flush 2" from end of pipe. Apply pressure to pipe. (See Figure 10.) Properly prep end of pipe. Only advance feedscrew in ¼ turn increments.
Pipe flared at grooved end.	Pipe and drive shaft not parallel. Feedscrew too tight.	Adjust stand to make pipe parallel. Only advance feedscrew 1/4 turn.

Troubleshooting (continued)

SYMPTOM	POSSIBLE REASONS	SOLUTION
Pipe drifts back and forth on driving roll axis while grooving.	Pipe length not straight. Pipe end not square with pipe axis.	Use straight pipe. Cut pipe end square.
Pipe rocks from side to side on driving roll while grooving.	Pipe stand is too close to end of pipe. Pipe end flattened or damaged. Hard spots in pipe material or weld seams harder than pipe. Grooving roll feed rate too slow. Power drive speed exceeds 57 RPM. Pipe supports stand not in correct location.	Move pipe stand in to match set-up Instructions. Cut off damaged pipe end. Use different pipe. Feed grooving roll into pipe faster. Reduce speed to 57 RPM. Position pipe stand rollers correctly.
Groover will not roll groove in pipe.	Maximum pipe wall thickness exceeded. Pipe material too hard. Adjustment screw not set. Power drive does not supply required minimum torque.	Check pipe capacity chart. Replace pipe. Set depth. Use RIDGID No. 300, 38-RPM Power Drive.
Groover will not roll groove to required diameter.	Maximum pipe diameter tolerance exceeded. Depth adjustment screw not set correctly. Pipe too hard.	Use correct diameter pipe. Adjust depth setting. Use different pipe.
Pipe slips on driving roll.	Grooving roll feed rate too slow. Driving roll knurls plugged with metal or worn flat.	Feed grooving roll into pipe faster. Clean or replace driving roll.
Groover will not rotate pipe while grooving.	Power drive does not supply minimum required torque. Chuck not closed on drive shaft flats.	Use RIDGID No. 300, 38 RPM Power Drive. Close chuck.
Pipe rises or tends to tip Groover over backwards.	Pipe support stand not properly set up.	Properly set up stands.