CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	CEMENT TOP		1X
В	Wooden legs		1X
С	Wooden legs		1X
H1	WASHER	0	2X
H3	BOLT M6x25		1X
H4	BOLT M8x50		2X
H5	ALLEN KEY		1X



Model#: VNN1021A


Product Dimensions: L47.52xW31.5xH17.72 inches




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 10 minutes.



Step 1: Use bolt M6x25 (H3) to conect wooden legs (B) and (C)



Step 2: The hardware need to connect wooden frame and concrete top are 4 bolt (H4) and

