

Item # 398 469 Model # MS102H

USE AND CARE GUIDE

GFCI OUTLET TESTER



Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service

8 a.m. - 6 p.m., EST, Monday-Friday

1-877-527-0313

HOMEDEPOT. COM

THANK YOU

We appreciate the trust and confidence you have placed in Commercial Electric through the purchase of this GFCI Outlet Tester. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Commercial Electric!

SAFETY SYMBOLS


| Symbol | Definition |
|-------------|--|
| \triangle | Indicates important safety information. |
| | Equipment protected throughout by double insulation or reinforced insulation. |
| Intertek | Conforms to UL STD. 61010-1, 61010-2-030 and 61010-031 |
| CAT II | (MEASUREMENT CATEGORY II) is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation. |

PRECAUTIONS

WARNING: BE EXTREMELY CAREFUL IN THE USE OF THIS DEVICE. Improper use of this device can result in injury or death.

Follow all safeguards suggested in this manual in addition to the normal safety precautions used in working with electrical circuits. DO NOT service this device if you are not qualified to do so.


CAUTION: Read, understand, and follow the safety rules and operating instructions of this manual before you use the product. Protection provided by the instrument will be impaired if used in a manner not specified by the manufacturer. Before measuring hazardous voltages, first measure the voltage which is known to determine if the equipment operates



CAUTION: All appliances or equipment on the circuit being tested should be unplugged to help avoid erroneous readings.

CAUTION: This is not a comprehensive diagnostic tester. It is a simple tester used to detect most probable, common wiring conditions. Refer all problems indicated by the tester to a qualified electrician.

CAUTION: This tester will not indicate quality of ground. This tester will not detect two hot wires in a circuit. This tester will not detects. A detect a combination of defects. This tester will not indicate reversal of grounded and grounding conductors.




Warranty

WARRANTY: 12 Months

For one year from the date of purchase, this product is warranted against any defects in material or workmanship. This warranty is void if this product is ever used while providing commercial services or if rented to another person. Contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Operation

PACKAGE CONTENTS



| Part Description | | Quantity |
|---------------------------|---------------------|----------|
| Α | Test plug | 1 |
| В | Test button | 1 |
| С | Indicator panel | 1 |
| D | Red indicator light | 1 |
| E Yellow indicator lights | | 2 |

HOMEDEPOT. COM
Please contact 1-877-527-0313 for further assistance.



2

Pre-Operation (Continued)


PRODUCT SPECIFICATIONS

| Component | Specification |
|-----------------------|--|
| AC Voltage Range | 125V AC, 50/60 Hz, 0.3W |
| Overload Voltage | CAT II 125V |
| Humidity | <80% relative humidity |
| Operating Temperature | 32°F to 104°F (0°C to 40°C) |
| Storage Temperature | 14°F to 122°F (-10°C to 50°C) |
| Altitude | <6560 ft. (2000 m), indoor use only |
| Dimension | 3.23 x 1.65 x 1.26 in. (82 x 42 x 32 mm) |
| Weight | Approx. 0.10lbs.(47g) |

4

Operation

- ☐ Press the test button on the installed GFCI that you are testing. It should trip. If it does not trip, do not use the circuit and consult an electrician.
- ☐ If the GFCI does trip, press the reset button on the receptacle and plug in the tester.
- ☐ Press the test button (B) on the tester for a minimum of 6 seconds. The red and yellow indicator lights (D and E) on the tester will shut off when the GFCI trips.
- ☐ Match the pattern of the red and yellow indicator lights (D and E) to a pattern on the indicator panel (C). See the Indicator Panel Definitions section of this manual for additional information.
- ☐ If the tester does not trip the GFCI, either the GFCI is operable but the wiring is incorrect, or the wiring is correct but the GFCI is inoperable.



Operation (Continued)

INDICATOR PANEL DEFINITIONS

indicate a faulty result. CAUTION: When testing in 2-wire (non-grounded) systems, the tester may

| Indicator | Fault | Reason for Wiring Fault |
|-----------|--------------------|-----------------------------------|
| 000 | Open ground | Ground contact not connected |
| 00• | Open neutral | Neutral contact not connected |
| 000 | Open hot | Hot contact not connected |
| ••• | Hot/ground reverse | Hot and ground contacts reversed |
| | | Hot and neutral contacts reversed |
| 0 • • | Correct | Receptacle is wired correctly |

RED YELLOW



Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

> 1-877-527-0313 HOMEDEPOT. COM

Retain this manual for future use.

Commercial Electric

5 HOMEDEPOT. COM Please contact 1-877-527-0313 for further assistance.