

## **INSTRUCTIONS:**

1. Remove old aerator from faucet.  
Use wrench if necessary.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads on faucet for easier installation.
4. For faucets with outside threads, unscrew adapter from spray aerator. For faucets with inside threads, keep adapter in place. Install onto spout by hand.
5. Turn on faucet. If leak occurs, tighten more firmly.

## **INSTRUCCIONES:**

1. Quite el viejo aireador del grifo.  
*Utilice una llave inglesa de ser necesario.*
2. Quite toda las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas del grifo para una instalación más fácil.
4. Para grifos con roscas externas, desatornille el adaptador del aireador de rociado. Para grifos con roscas internas, matenga el adaptador en su lugar. Instale en el surtidor de agua en forma manual.
5. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.