



Model # TDIDVKHD6

# Use and Care Guide

## Indoor Dryer Vent Kit

**EVERBILT**

### TOOLS REQUIRED



Screwdriver or  
5/16" Nutdriver

### HARDWARE REQUIRED (NOT INCLUDED)



Screws (4)

## Installation

- 1 USE OF MOUNTING RING IS OPTIONAL. ATTACH MOUNTING RING TO A STUD OR DIRECTLY TO DRYWALL USING SCREWS OR SCREWS / DRYWALL PLUGS (NOT INCLUDED).**
- 2 HALF FILL THE BOTTOM OF THE RESERVOIR WITH WATER THEN SNAP ON COVER**
- 3 SLIDE ONE END OF THE DUCT OVER THE TOP COLLAR OF THE RESERVOIR AND SECURE WITH ADJUSTABLE CLAMP.**
- 4 SLIDE OTHER END OF THE DUCT OVER DRYER OUTLET AND SECURE WITH ADJUSTABLE CLAMP.**
- 5 EMPTY AND REPLACE WATER AFTER EVERY USE.**

## Warranty

### WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

### WHAT IS NOT COVERED

This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance call 1-800-305-1726 or visit [www.HomeDepot.com](http://www.HomeDepot.com).



Modelo # TDIDVKHD6

# Guía de uso y cuidado

## Juego para respiradero interno de secadora

**EVERBILT**

### HERRAMIENTAS NECESARIAS



Destornillador o llave  
de tuerca de 5/16"

### MATERIAL Y HERRAJES NECESARIOS (NO SE INCLUYEN)



Tornillos (4)

### Instalación

- 1 EL USO DEL ARO DE MONTAJE ES OPCIONAL. FIJE EL ARO DE MONTAJE A UN MONTANTE O DIRECTAMENTE AL TABLERO DE PIRCA, USANDO TORNILLOS O TAPONES ROSCADOS/PARA TABLERO DE PIRCA (NO INCLUIDOS).**
- 2 LLENE EL FONDO DEL TANQUE HASTA LA MITAD CON AGUA Y COLOQUE LA TAPA.**
- 3 DESLICE UNO DE LOS EXTREMOS DEL CONDUCTO POR ENCIMA DEL CUELLO SUPERIOR DEL TANQUE Y ASEGURE CON LA GRAPA AJUSTABLE.**
- 4 DESLICE EL OTRO EXTREMO DEL CONDUCTO POR ENCIMA DE LA SALIDA DE LA SECADORA Y ASEGURE CON LA GRAPA AJUSTABLE**
- 5 VACÍE Y CAMBIE EL AGUA LUEGO DE CADA USO.**

### Garantía

#### ¿QUÉ SE CUBRE?

Toda la mercancía se garantiza contra defectos de fabricación y de los materiales durante un año a partir de la fecha de compra. Esto incluye el desgaste y las fallas en el desempeño normales de los artículos. El fabricante reemplazará o reparará el artículo a su criterio.

#### ¿QUÉ NO SE CUBRE?

Esta garantía cubre únicamente el desgaste y las fallas en el desempeño normales. No cubre el mal funcionamiento, las fallas en el desempeño ni los defectos que surjan debido al mal uso, el abuso, la negligencia o la modificación del producto. No están cubiertos los daños ni el mal funcionamiento que se cause al producto por parte del usuario o otras fuentes externas, ni las fallas debidas al incumplimiento de las advertencias y las instrucciones.

Para obtener más ayuda llame 1-800-305-1726 o visite [www.HomeDepot.com](http://www.HomeDepot.com).