



ASSEMBLY INSTRUCTIONS

OUTDOOR WOOD PELLET HEATER

Model: Q 05

1. Assembly

Note: Partial assembly has been done for you. The assembly of this heater requires basic mechanical skills. Proper assembly is the responsibility of the purchaser. All service and repairs should be done by a qualified person.

Tools required for assembly are:

Phillips Screwdriver

pliers

1.1 Unpacking

Carefully remove the all parts from the box. The paint on the stove is not fully cured until after you fire the unit on its initial firing, so use care when handling painted parts and put them onto soft surface.

Find and identify the following parts:



1.2 Checking Every Part:

Inspect the contents of your new heater for shipping damage or missing pieces or hardware.

1.3 Installing the feet:

Lean the base of the heater back or lay and its front to thread in the feet to the bottom.





Assemble the ash drawer handle by installing 2 screws and nuts to the tray. Then slide it into place.



Install the section of chimney on the base of the unit that does not have the damper. Then install the damper section next. Interlock the stove pipe so they lock into place and are even at the edges. Fit the longer section to the screened section.





Thread the 3 screws through the tabs into the deflector disk. Then attach the long section of stove pipe to the completed screened section. Place the top stack onto the heater assembly.



Once the stove pipes are firmly fitted together it is complete.

**SEE MORE STOVES AND FIREPLACE PRODUCTS, CHECK THE ELECTRONIC
VERSION OWNER'S MANUAL AND INSTALLATION VIDEO, PLEASE VISIT:**

WWW.QSTOVES.COM

WEAR PROTECTIVE GLOVES WHEN ASSEMBLING.

CAUTION!

PAINT IS EXTREMELY FRAGILE PRIOR TO CURING.

GENTLY UNWRAP ALL PARTS.

DO NOT SET PAINTED PARTS ON ABRASIVE SURFACES.

Version 5.1