

How to Hang Curtain Brackets

After you've finished taking measurements, it's time to hang the curtain rod. To do so, you'll need to first install the curtain brackets:

1. Measure up to the height of your curtain panels. From there, use a pencil and tape measure to mark curtain bracket placements six inches from the outside edge of the window frame to allow plenty of natural light.
2. Use a screwdriver to install curtain brackets; make sure the sides are even using a level.
3. Place curtains on the rod, then hang curtains.