

Envirotile™ Stair Treads
Installation Recommendations

To ensure secure placement, we recommend Envirotile™ stair treads be fastened to the floor surface. On a wooden deck, anchor the stair treads with wooden deck screws. On concrete, use silicone adhesive such as PL Premium (available at Home Depot). We recommend the application of adhesive or wood screws should be reviewed from time to time, to ensure the treads remain completely secure.