



Insert lattice (part 9) through 27½" center cross rail (part 4). Insert one end of lattice into 27½" bottom cross rail (part 3) and other end into 27½" top cross rail (part 5). Insert one end of three cross rails into corresponding holes in left post (part 1). Insert bent top (part 6) into left post. Insert one 11" tube (part 8) and one 9½" tube (part 7) into left outer hole of top cross rail, with 11" tube on outside (left side). Insert one 9½" tube (part 7) into hole in middle of top cross rail. Insert one 9½" tube (part 7) and one 11" tube (part 8) into right outer hole of top cross rail, with 11" tube on outside (right side). Insert free ends of tubes into bent top. Insert free ends of bent top and cross rails into right post (part 2). Using six 1¼" screws, screw together trellis. Be sure that all parts are fully inserted into legs before.

If combining with Model# 11153 Large Green Lattice Planter or Model# 11154 Large White Lattice Planter to make a planter trellis, use a straight blade screwdriver to pop off two 2" sq. post caps of one long side of the planter and slide trellis over the planter legs. Using two 1" painted self-tapping screws from trellis ground anchor kit (part 11), fasten trellis to planter.