



**IMPORTANT:**  
**TURN OFF POWER AT MAIN FUSE OR**  
**CIRCUIT BREAKER BOX BEFORE**  
**STARTING INSTALLATION**

**Carefully unpack and identify all parts before assembly. Bulb not included.**

1. Follow enclosed supplement installation instructions for electrical and fixture installation onto house outlet box. If you do not have an outlet box at desired location to attach the fixture than hire a qualified electrician to create one.
2. Install bobeche by slipping through socket until it securely sits onto fitter.
3. Slip candle tube over socket.
4. Install bulb (not included). See relamping label located near socket area for type and maximum allowed wattage.
5. Hang all crystal glass parts as shown on drawing. NOTE: To replace broken crystals extras are included in hardware bag. Replace by gently bending open pin, remove broken crystal, hook new one, then close back pin. Avoid bending pin into sharp angle.