

Swiss Madison
well made forever

SM-1T257

SUBLIME II

Floor anchor
placement
template

Wall

Place template on the
floor above the flange.

Outer Rim of Flange

X

4 1/2"

Drill here

X

Anchors

4"

Drill here

X

Anchors

7 3/8"

Front of Toilet

