

---

# **CON-TACT LINER**

## **CREATIVE SURFACES**

### ***Self Adhesive***

---

#### **SURFACE PREPARATION**

Clean surfaces prior to application as necessary  
All surfaces should be dry, clean, and smooth

#### **APPLICATION**

Measure area to be covered  
Carefully cut to fit using the lines on the backing paper as a guide  
Leave approximately 1/8" overlap on all edges for probable shrinkage over time  
Start at a corner and peel off the backing paper to apply  
Smooth from center out to help eliminate bubbles of air

#### **CLEANING AND MAINTENANCE**

Clean by simply wiping the surface with a damp cloth and mild soap if necessary

#### **REMOVAL**

Peel adhesive liner off of covered surface piece by piece  
To remove excess adhesive apply a citrus-based solvent to the surface where the contact paper was applied  
Allow the solvent to sit for approximately 5 minutes to dissolve the remaining adhesive  
Scrub the surface with a sponge to remove adhesive residue  
Rinse the sponge in clean water and wipe the surface to remove any excess solvent  
Leave doors and drawers open to allow the interior of cabinets and drawers to dry

To remove stubborn pieces, first heat the surface to loosen the adhesive's grip (e.g. blow dryer on low setting) then follow the steps listed above.

