

Instructions



Instructions for replacement of Bonaire Durango Rooftop Filtercool pads



Before commencing any maintenance work on your unit, ensure it is disconnected from the power supply.

1. **Remove the Grill**
 - a. Refer to the Owner's manual for detail
2. **Remove the old Filtercool pads**
 - a. Remove the spike and clip (discs) that fasten the Filtercool pads to the grill and remove the Filtercool pads.
 - b. After removing the Filtercool pads remove the spike and clip (discs) that fasten the Filtercool pad to the grill.
 - c. NOTE: If the cooler has not previously had pads changed it may have integrated spikes molded into the Rear panel. Integrated spikes may require removal.
3. **Install the new Filtercool pad**
 - a. Fit the Filtercool pad inside the grill.
 - b. Ensure the water distributor section is at the top of the Filter cool pad (see image below)
 - c. Secure the Filtercool pad using 4 spikes and clips. (see image below)
4. **Refit the Grill**
 - a. Refer to the Owner's manual for detail

