



TITE FOAM



Exterior Project Guide



Fill the space around the pipe to prevent water from getting out and air from getting in.



Don't let gaps like this be the cause for high energy bills.



LOCTITE TITEFOAM EXTERIOR APPLICATIONS

- Wiring & Plumbing Penetrations
- HVAC Penetrations
- Dryer Vent
- Pest entry locations
- Outside water faucet
- Exterior walls/siding

**TITEFOAM FILLS UP GAPS AND CRACKS
SEALING THE WEATHER OUT & THE SAVINGS IN**

LOCTITE

**TITE
FOAM**



Interior Project Guide



SILL PLATE

Use foam to insulate the gap between the wood and concrete to prevent heat loss.



DRYER VENT

Block out pests and eliminate air infiltration by insulating the gap between the dryer vent and dry wall.



LOCTITE TITEFOAM INTERIOR APPLICATIONS

- Wiring & Plumbing Penetrations
- HVAC Penetrations
- Pest entry locations
- Around perimeter of electrical outlets (Not inside outlet box)
- Under baseboards
- Sill Plate
- Rim Joist
- Dryer Vent
- Under baseboards
- Floor/Wall Joints
- Attic Hatch Frame

**TITEFOAM FILLS UP GAPS AND CRACKS
SEALING THE WEATHER OUT & THE SAVINGS IN**