



**INSTRUCTIONS:**

- 1) APPLY PLUMBER'S PUTTY OR SEALANT TO UNDERSIDE OF STRAINER BODY OR TOP OF SINK DRAIN FLANGE AREA.
- 2) ASSEMBLE AND TIGHTEN SECURELY ALL COMPONENTS (3,4,5&6) IN SEQUENCE AS ILLUSTRATED.
- 3) CHECK FOR LEAKS BEFORE USE.