



INSTRUCTIONS :

1. - Using a screwdriver, push the tip of the DrillerToggle® into drywall and turn clockwise until the threads go through the wall.
2. - Push the DrillerToggle® until the helix is flush with the wall and the arrow at 7 o'clock (as shown in picture 3).
3. - Turn clockwise until the DrillerToggle® head is flush with wall and the arrow at 12 o'clock.
4. - Insert the screw through the object you need to affix and into the DrillerToggle® and push until you feel a resistance.
5. - Turn the screw clockwise until firmly in place.

WARNINGS :

- Do not use in insulated drywall.
- To deploy properly, the anchor needs a **MINIMUM** clearance of 2-5/8" behind the gypsum board.
- Be sure to install the anchor at a **MINIMUM** distance of 2" from the wood studs behind the gypsum board.