

BASIC INSTRUCTIONS FOR #67252

A. PRE ASSEMBLY OF RISER

1. TEFLON TAPE BOTH ENDS OF RISER
2. ATTACH BUSHING TO BEND IN RISER, ONE SIDE FITS RISER / OTHER SIDE FITS SHOWER HEAD
3. TEFLON TAPE OUTSIDE OF BUSHING FOR SHOWER HEAD

B. ASSEMBLE WALL BRACKET FOR RISER

1. SLIDE WALL BRACKET ASSEMBLY OVER BOTTOM PORTION OF RISER
2. HAND TIGHTEN SET SCREW

NOTE: DO NOT OVER TIGHTEN SET SCREW

C. ATTACH RISER TO FAUCET BODY

1. PUSH NUT & WASHER ONTO BOTTOM OF RISER
2. TEFLON TAPE THREADED PORTION OF FAUCET BODY
3. SCREW RISER INTO FAUCET BODY & TIGHTEN WITH WRENCH

D. ATTACH SHOWER HEAD TO TOP OF RISER (ONTO BUSHING)

E. ADJUST HOT / COLD SIDES OF FAUCET TO ALIGN WITH SUPPLY LINES

1. TEFLON TAPE SUPPLY LINE & ATTACH FAUCET BODY TO THEM

F. WITH SUPPLIE WOOD SCREWS, ATTACH WALL BRACKET TO WALL

G. TIGHTEN NUTS ON HOT & COLD SIDES WITH WRENCH

H. TURN ON WATER SUPPLY, CHECK FOR LEAKS

*NOTE: USE TEFLON TAPE ON ALL THREADED CONNECTIONS

NOTE: MAKE SURE TO DRAIN ALL EXPOSED PARTS IN AREA'S WHERE FREEZING OCCURS