



How-To-Use

Sika® PostFix®

Expandable Fence Post Mix

Materials:

- Safety glasses and gloves
- Scissors or utility knife
- Bag of Sika Post Fix

Site Prep and Procedure

1. Dig your hole. Make sure that the post is adequately positioned inside the hole and leveled and braced (or held manually) before mixing. If there is standing water in the hole, backfill partially with soil or gravel until water is no longer visible or pump the water out.
2. Wear safety glasses and gloves. Roll the pouch (in direction of arrows) toward the central burst seal until it ruptures and allow materials to combine.
3. Mix thoroughly by rubbing the bag along any 90 degree surface (no sharp edges that would puncture the bag) for **15 SECONDS** by forcing material to travel in the bag from one end to the other.
4. **IMMEDIATELY** after mixing, cut one of the bag's corners and pour the mixed material evenly around the hole before expansion starts (material color is green).
5. Adjust the post if necessary for up to 10 seconds. Do not move the post until material has firmed up. Hardening will be achieved in approximately 3 minutes; thereafter, the post may be left unsupported. Allow approximately 2 hours for the product to set completely before installing the fence, gate or any other accessory on the post.
6. Remove excess material immediately using either a solvent-based cleaner or clean cloth to remove splatters of uncured material from the post's surface. Hardened material can only be removed with a hand tool.