

### STEP 1 Install the base

Lay the base according to following picture, please note connector is the same direction.



### STEP 2 Install side panels and back panels

Insert side panel and back panels according to arrow direction.



### STEP 7

Press each vertical panel after install, to keep connectors insert panels firmly.



Note:  
1.Keep panel and connector tightly.  
2.Be laid flat.  
3.Keep upright and avoid collision.

### STEP 3

Insert back connector according to following picture into all of connector in same direction.



### STEP 4 Insert top panel

Insert panel according to following picture.



### Clothes rod Installation diagram

Should be handled before insert the top panel



### STEP 5 Install door panel

Insert metal frame of door into connector and keep the connector into storage cabinet.



### STEP 6

According to previous assembly way to assemble 2 types cabinet.

