

OUTDOOR

Window Insulation Kit

Preparation: Be sure surface is clean, dry and grease-free. Install only on metal, painted wood or vinyl. DO NOT APPLY to veneer, cement, or uncured painted surfaces.

Installation:

1. Apply tape firmly around window frame. Remove backing paper;
2. Apply film slightly taut first across top, then bottom and both sides, leaving at least 1" overhang around edge. Pull and stretch film to smooth out any wrinkles.
3. Trim excess film from around frame.



Kit de aislamiento para ventana

EXTERIOR

Preparación: Asegúrese que la superficie esté limpia, seca y libre de grasa. Instále solo sobre marcos de metal, madera pintada ó con revestimiento de vinilo. NO APLIQUE a paneles de chapa, cemento o superficies pintadas sin curar.

Instalación:

1. Aplique la cinta de doble cara alrededor del marco de la ventana. Remueva el papel de reverso.
2. Aplique la película levemente estirada a lo largo del tope, la parte inferior, y los lados, dejando al menos 1 pulgada (2,54 cm) extra alrededor. Jale y estire la película para alisar cualquier arruga.
3. Recorte el exceso de película alrededor del marco.

TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?
Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions