

Shiplap Siding Installation

To make sure your **shiplap siding** installation goes as quickly and easily as possible, here are some general guidelines. Remember that these are guidelines only; you must consult your local building codes or a professional siding installer in your area. Consulting your local building department or HOA prior to starting exterior renovations to either a residential, or commercial building is a required step in any project.

1. Apply a vapor barrier to the wall.
2. Attach 3/4" furring strips over the vapor barrier every 16".
3. Start at the bottom of the wall. To start the installation of a siding board pre-drill holes above each furring strip with a 1/8" drill bit.
4. Drive a 3" stainless steel screw through the 1/8" pre-drilled hole in the last step. This will secure the bottom half of each siding board.
5. Next, with a 1/8" drill bit predrill a hole through the narrow part of the siding board that protrudes against the wall on the top of the board.
6. Drive a 3" stainless steel screw through the 1/8" pre-drilled hole in the last step. There is no need to worry about plugging this hole as the next board that is installed will cover this fastener.
7. Repeat the above steps for the rest of the siding boards up the wall.