



Installation of Privacy Fence Netting

The goal of a proper installation is to have a properly positioned, wrinkle-free privacy netting installation. **DO NOT ATTEMPT INSTALLATION ON A WINDY DAY.**

Equipment Needed: 7" – 50lb zip ties, hog ring pliers and hog rings (optional), ladder (depending on height of fence)

Layout entire length of the privacy netting and start by securing the top beginning edge with a zip tie to the fence. Secure the privacy netting at the proper height - typically, the bottom of the netting would be 6" off of the ground to allow air to pass and avoid damage from weed eaters.

Secure the bottom starting edge with a zip ties as well; make sure the starting edge is straight. This helps keep the netting tight and wrinkle free.

Use temporary S hooks to take vertical weight and load off the entire length of the netting. Pull the slack out as you go along.

Secure the top edge of the privacy netting with zip ties through ALL button holes, ensuring the netting is tight as you move down the length of the netting. Do NOT skip button holes.

Go back and pull the vertical slack out of the netting vertically and attached the bottom button holes.

If you want a more permanent installation; you can go back with a hog ring pliers and use steel hog rings to secure your privacy netting.