

Installation

1. Put the bushing into the hole on wall or door
2. Have cable Passed through the hole cover

