


SILICONE Teardrop Profile Self-Stick Weatherseal

For best results, ensure surfaces are completely dry and free of dust, grime or grease. Install while temperatures are roughly between 40°-90°F (5°-32°C).

Installation: Separate the strips (if necessary) and unwind approximately 12" to start. Remove backing paper and press adhesive side of tape firmly onto window or door frame. Cut excess with scissors or razor.

Windows: Apply on upper and lower window sashes between window and window sill.

Doors: Apply to door stop molding across the top and down hinge side. Apply to inside of door across top and down latch side



SILICONA Perfil de lágrima Burlete autoadhesivo

Para mejor resultado, asegúrese que las superficies estén secas y libre de polvo, sucio o grasa. Instále cuando las temperaturas estén alrededor de 40°-90°F (5°-32° C).

Instalación: Separe las tiras (si es necesario) y desenvuelva aprox. 12" para comenzar. Remueva el papel de reverso y presione el lado adhesivo del burlete firmemente contra el marco de la ventana o puerta. Corte el exceso con tijeras o navaja.

Ventanas: Aplique al marco superior e inferior entre la ventana y la repisa.

Puertas: Aplique al molde del marco a lo largo del tope y del lado de los goznes. Aplique al interior de la puerta a lo largo del tope y lado del herraje.

