

SAFETY FENCE INSTRUCTIONS

- **PLACE 1 FENCE POSTS NO MORE THAN 8 FT APART FROM EACH OTHER**
- **DRIVE POSTS IN APPROXIMATELY 1.5 FT DEEP USING A MALLET**
- **LINE UP FENCE ON POSTS BY STRETCHING THEM ACROSS POSTS AND ATTACHING THEM WITH TIES.**
- **TIGHTEN FENCE AND SECURE WITH CABLE TIES TO POST, MAKE SURE TO USE AT LEAST 3-5 TIES TO SECURE THE FENCE.**

NOTE: IN HIGH WIND AREAS, IT IS HIGHLY RECOMMENDED THAT THE FENCE BE TIED BETWEEN THE FLAT SIDE OF THE METALS POSTS AND A WOOD SLAT.

SUGGESTED TOOLS:

T-POSTS

CABLE TIES

WOOD SLAT

MALLET