
# **INSTRUCTION MANUAL**



## **PACKING LIST**

Pre-assembled cabinet

11 3/4"

11"

- Countertop
- 1 Sink
- 1 Mirror

Mirror mounting screws

11"

Drain

14 3/8"


Instruction Manual


#### WARRANTY


Design Element warrants cabinets, mirrors, finishes and fittings to be free from defects in workmanship and materials under normal use and service for a period of one (1) year.


Please report any damage or missing pieces of your vanity to us immediately. These things must be reported no later than 30 days from the date of delivery.

### **Attaching Sink To The Counter Top**











- 1. Apply continuous stream of silicon glue on circumference of the sink.
- 2. Turn the counter top upside down and provide support from beneath. (Note: While turning around the double sink counter tops, always add support from the centre for safety)
- **3.** Put the glued sink over the cutout and attach it firmly.
- **4.** Tie up screws positioned at the respective places on the counter top.


## **Attaching Counter Top To Cabinet**







- 1. Apply continuous stream of quality silicon glue to the top of the cabinet where the countertop needs to be
- **2.** Place the countertop on the glued
- 3. Don't start using the vanity right away. Wait for approximately 24 hours so that the silicon glue can dry.

## **Installing The Drain On The Sink**










- 1. After installing the counter top on the cabinet, put the drain assembly inside the hole in the sink and fix it firmly 2. For the overflow sinks, make sure that the overflow hole on the drain is aligned straight in the direction of the overflow hole on the sink.
  - 3. Tie up the mounting rubbers and metal rings from the bottom of the drain.


  - **4.** Connect the trap onto the drain bottom.

## **Hanging Mirror On The Wall**









- 1. Measure the distance between the screw holes from the back of the mirror.
- 2. Locate the studs on the wall. They are normally placed 12" to 16" apart from each other. Drill two holes on the studs as per your previous measurement.
- 3. Insert the plastic plugs into the drilled holes and then insert screws into the plastic plugs. Tie up the screws till they remain at least 0.5'' - 0.75'' outside the
- 4. Hang the mirror on to the screws.

#### SAFETY AND PRECAUTIONS

- · Please go through this entire instruction manual before making any attempt to assemble, operate or install the product.
- During installation, handle the countertop and sink with optimum care. They might break if hit hard on a solid surface.
- Don't start using the vanity right away. Wait for approximately 24 hours after installation so that the silicon glue can dry.
- When scrubbing the cabinet while cleaning, make sure you do not remove or scratch the finish.

#### **CARE AND CLEANING**

- · Avoid using any type of rough cleaning material on top of the cabinet
- Use mild liquid soap and water-dampened soft cloth to remove stains from the cabinet and to clean the marble countertop.
- For the glass part of the mirror, use ammonia-free cleaning products.

## **CONTACT SUPPORT**

PHONE: (888) 487-4488

**EMAIL:** cs@designelementusa.com

ADDRESS: 8715 Boston place, Rancho Cucamonga, CA. 91730

www.designelementusa.com





## **INSTRUCTION MANUAL**

SKU CODE:

#### **MUT-W**

**FRONT** 





**COLLECTION:** London

**DIMENSIONS:** W 29 3/4" | D 22" | H 30"

#### **PRODUCT OVERVIEW**

- Solid oak wood construction
- White finish.
- Featuring a marble countertop surface
- 1 Pull-out drawer.
- 7 slots inside the drawer to store your items.

#### **WARRANTY**

Design Element warrants marble, fittings and finishes to be free from any defect in workmanship and materials under normal use and service for a period of one (1) year. In case of any damage, report it within 30 days.

#### CARE AND CLEANING

- Avoid using any type of rough cleaners or chemicals on the finish.
- Cabinet finish is water resistant, use mild liquid soap and a soft cloth to clean the cabinet body.
- Scrub the cabinet smoothly, while taking care not to remove or scratch the finish.
- Use a mild liquid soap and a soft cloth to clean white carrera marble piece placed on top of the Make up table.

#### CONTACT SUPPORT

PHONE: (888) 487-4488

**EMAIL:** cs@designelementusa.com

ADDRESS: 8715 Boston place, Rancho Cucamonga, CA. 91730

