

Use and Care Manual



3D Wood Wallscapes must be installed according to the installation guide and maintained in an environment where the humidity is between 35% and 60%. Do not install the panels in bathrooms, shower rooms, or other rooms exposed to excessive moisture. Allow 48-72 hours for the panels to acclimate to room temperature. The application surface should be clean and dry.

MAINTENANCE

Do not apply water to the surface. Use a hardwood cleaner or a soft and dry brush.



PROPOSITION 65 WARNING: Drilling, sawing, sanding, or machining wood products generates wood dust, a substance known to the State of California to cause cancer. Use a respirator or other safeguards to avoid inhaling wood dust.

American Pro Décor assumes no liability for improper installation