

Under Sink Mat



- 1) Prepare Surface
 - Apply only to clean, smooth surface. To clean, use soap & water. Rinse & dry thoroughly.
 - Products may not adhere to fabric, rough or pebbly surfaces or surfaces under 55°F (13° C).
- 2) Measure & Cut
 - Allow at least 3/8" (1cm) overlap on all edges for possible shrinkage.
- 3) Apply
 - Beginning at the center, press out towards edge using squeegee, straight edge tool or cloth.
 - Covering may be lifted and repositioned during application to eliminate bubbles or wrinkles.
 - Avoid pulling or stretching.

