

Setup

Start

Preparing the work area:

Texture spraying creates a great deal of dust and overspray material. It is necessary that you cover with drop cloths anything you do not want sprayed (walls, windows, floors, furniture) and remove as many non-essential items from the room as possible.

Make sure the work surface has also been properly prepared. Application over unsealed, stained, improperly prepared, or not completely dry surfaces may cause discoloration and adhesion problems.

Questions?

Call Wagner Technical Service at:

1-800-328-8251

Register your product online at:

www.wagnerspraytech.com

