

CLOSURE VENT CV3

Closure Vent is die cut to perfectly fit the Classic Rib panel profile and does not require a special ridge cap.

The adhesive is designed to make application easier, keeping the vent in place until the ridge cap is fastened.

INSTALLATION INSTRUCTIONS

Simply install your roof panel with a two inch opening between the top of the panel and the peak of the roof then follow these simple instructions:

- 1. Peel paper from adhesive on vent**
- 2. Place Closure Vent on the panel with screened piece toward the front – position so that fasteners will go through the web of the closure when the ridge cap is installed**
- 3. Install ridge cap**