



# SureCorner™ Corner Flashing for Windows



[WWW.SURESILL.COM](http://WWW.SURESILL.COM)

## SureCorner™ Water Management Guide

### STEP 1

Install continuous Bead of sealant 1/2" in diameter in lower corners of the rough opening. Attach skirt by stapling skirt under rough opening.



### STEP 2

Install continuous Bead of Sealant 1/2" in diameter on the back of the SureCorner™ along perimeter edge.



### STEP 3

Press or roll SureCorners™ so that the Sealant flattens out. Mechanically attach SureCorner with staples near the edge.



### STEP 4

Properly flash SureCorners™ to rough opening using high quality SAF flashing material. Roll SureCorners™ and Flashing material.



Recommended Sealant: QuadMax™ by Henkel/OSI®, Recommended Flashing Tape: TiteSeal™ Butyl Self Adhering Flashing; Butyl Flash, by OSI/Henkel.

SureSill™ and SureCorner™ are patent-pending technologies made only by SureSill, Ltd. SureSill™ and SureCorner™ are exclusive trademarks of SureSill, Ltd. Copyright 2007 – 2015 SureSill, Ltd. All rights reserved.