

How to Measure

MOUNTING INSIDE

1



Measure the window depth to ensure you have enough space for an inside mount
2.5" Non-Valance
3.5" Full Valance

2



Measure your window W & L in 3 different places. Record the narrowest/longest measurement to the nearest 1/8", round down if needed to ensure accurate measurements.

How to Measure

MOUNTING OUTSIDE

1



Measure the width of the space, add at least 4" (2" on ea. side) to allow for overlap

2



Measure the height, ensure you have enough flat space above the window to properly install the shade and allow for overlap at the bottom.