

# Side Kit Mirror Installation

- 1、 Attach the side kit brackets thru the pre-punched holes in your cabinet.
- 2、 Try to use the first row from the top and bottom of your cabinet. Using the 10-32\*1/2" screws fasten the brackets and finish with screw caps.
- 3、 Attach the 2"\*2" foam pads on two sides of cabinet.
- 4、 Clean the backside of the side kit mirror panel with the Alcohol pads. Check alignment before you attach the mirror to be sure it will align even with the top of the cabinet
- 5、 Peel off tape backing of the adhesive tape on the side kit brackets and foam pads. Carefully align the mirror to the cabinet evenly on all four sides. Press firmly into place and attach to the side kit mirror to the cabinet body.

