

Installation Guide

- Sweep the entire surface clean of any debris
- Install the underlayment on the cleaned surface. Exactly as it unrolls – vapour barrier up
- Simply cut off any excess once installed using a standard utility knife
- Affix joints using standard tuck tape
- Install the flooring as per manufacturer's instructions directly on the acoustic membrane