

Oxford Trellis

Model# 11175

Assembly Instructions



<u>Part #</u>	<u>Description</u>	<u>Qty</u>
1	2" sq. x 65" Corner Post	1
2	2" sq. x 59½" Left Post	1
3	2" sq. x 59½" Right Post	1
4	7/8 x 1½ x 20" Top/Bottom Cross Rail	4
5	7/8 x 1½ x 19" Bent Top	2
6	¼ x 1½ x 49" Vertical Slat	4
7	¼ x 1½ x 19¼" Horizontal Slat	12
8	2" sq. x 14" Vinyl Ground Anchor	3
9	Hardware Bag (includes:)	1
	2" sq. Post Cap	3
	¾" Painted Screw	8

General Information

PLEASE READ THROUGH BEFORE BEGINNING ASSEMBLY.

IMPORTANT: Check boxes for Contents Listed

Check inside of parts as some parts are packaged
inside of others

In the event of missing, damaged or defective parts
please call our customer service dept. at 1-877-258-6020

When assembling components, place on a clean, flat
non-abrasive surface to avoid scratches

Tools Required

- ... Battery or Electric Drill with #2 phillips bit
- ... Tape Measure
- ... Hammer or Rubber Mallet (recommended)
- ... PVC, Super, or Crazy Glue