

Ready To Assemble Barn Door

11/1/2013



Assembly:

- 1) Lightly sand and slightly round the exposed corners with sand paper to avoid splinters.
- 2) Stain the wood before assembly.
- 3) Line up the long tongue and groove boards, choose which side you want to show and arrange boards accordingly.
- 4) Decide what pattern of door you will assemble and lay out the cross members accordingly.
- 5) Check for squareness of the door by measuring from corner to corner.
- 6) Screw down cross members with screws provided. Do not over tighten the screws, make them flush with the surface. If the screw is in a knot, countersink for that screw head to make it flush.
- 7) If needed touch up the stain where needed. It might be necessary to round the corners after assembly, stain as needed. Finish as desired.

Finishing Tip:

Be sure to stain the tongue and grooves before assembly.



Optional Assembly styles of the Door

