

How to Install Static Cling Window Film

1. Before installation, make sure that your surface is clean, dry and smooth. Our window films are for indoor use only and should be installed in a room of moderate temperature.
2. Start by spraying your glass surface with water. Peel off the film's protective backing and position on glass.
3. Working from the center outward, smooth the film into place and work out any air bubbles with a squeegee or smoothing tool such as a credit card.
4. Trim any excess material with a craft or utility knife. Your film may appear cloudy at first but will become clear once the water evaporates.
5. If you need to reposition or remove your window film, simply peel away from a top corner.
6. After being removed, you may use the window film on another window or reposition it using the same steps.