

INSIDE THE BOX: GLASS SHELF AND HARDWARE (4 MOLLYS, 6 SCREWS, and 2 BRACKETS)



RECOMMENDED TOOLS



DRILL



TAPE MEASURE



LEVEL



HAMMER



PENCIL

- 1) Remove the shelf and hardware from the packaging.
- 2) Place the shelf up against the wall where you wish to install it then mark on the wall with a pencil a fist length from the edge in.
- 3) Remove the shelf and use your drill to drill holes where you marked with a pencil.
- 4) Insert the included mollys one at a time into the holes you drilled using a hammer.
- 5) Take your brackets apart. Your brackets come apart, you will have an upper bracket and a bottom bracket. The small bracket is your upper bracket.
- 6) Take the upper bracket (small one) and place the bottom hole over the molly and insert the screw through.
- 7) Insert the bottom part of the bracket and tighten the screw at the bottom being sure to leave some space in between for your shelf.
- 8) Insert your shelf into the space and tighten the bottom screw making sure that the brackets are tightly gripping the shelf.



CONGRATULATIONS!

Installation of your new shelf is complete! Enjoy!