

## Instructions for Gap Gone Installation

### (SIDES)

1. Unpack the box which contains the following items;
  - a. (2) sides
  - b. (6) clips
  - c. Pack of 12 screws
2. Ensure that the windows blinds are installed to place the sides over the sides attached to the window frame
3. Measure the inside of the window frame from the top to the windowsill (3) times. (Measure (3) times to ensure an accurate measurement)
4. Cut the sides to the length of the window frame with the cut portion facing up to cover the blinds rail.
5. Put the clips in the allocated holes on the clip sides.
6. Dry fit the sides to the desired depth
7. Peel of the clip backing and press firmly on the sides of the window frame.
8. Once installed please allow 24 hours for the glue to adhere to the window frame for a tight fit
9. Enjoy your new Gap Gone window treatment