



Installation/Usage

wedi Subliner Dry Waterproof Sealing Tape | Waterproofing Shower and Wet Area System



wedi Subliner Dry Waterproof Sealing Tape
wedi Part Number: US5000002
1 Roll: 5 in. x 32.8 ft.

wedi Subliner Dry Waterproof Sealing Tape is applied over suitable surfaces (substrates also generally suitable for tile as per tile Council of North America) using cement based tile adhesive and a 3/16" x 1/4" or 1/4" x 1/4" notched tile adhesive trowel.

The logo side of the tape is the top side.

The sealing tape is pressed flat into the notch trowel combed tile adhesive bed using the flat side of the tile adhesive trowel or a rubber or wooden float.

Air pockets must be removed from under the sealing tape using trowel or float.

In wet areas such as showers, a joint sealant such as wedi joint sealant is applied over the tape seams to bar water from migrating below the sealing tape through the tile adhesive.

Tiling can commence once the tile adhesive has initially hardened/cured.

The product is not used in areas with water pressure/standing water.