

How to Install Self Adhesive Window Film

1. Before installation, make sure that your surface is clean, dry and smooth. Our window films are for indoor use only and should be installed in a room of moderate temperature.
2. Start by spraying your glass surface with a light spritz of water. This will allow you to slide around the film to position it just right. Follow by peeling off the film's protective backing and positioning on glass.
3. Working from the center outward, smooth the film into place with a squeegee or smoothing tool.
4. Easily trim any excess material with a craft or utility knife. Your film may appear cloudy at first but will become clear once the water evaporates.
5. If you need to reposition or remove your window film, simply peel away from a top corner.