Installation

1. Confirm the diameter of hole and choose a correct size

2. Put the hole coer into the hole on desk

Press into hole

Hole

3. Let cable Pass through the hole cover