
CON-TACT LINER

CREATIVE COVERINGS

Self Adhesive

SURFACE PREPARATION

Clean surfaces prior to application as necessary
All surfaces should be dry, clean, and smooth

APPLICATION

Measure area to be covered
Carefully cut to fit using the lines on the backing paper as a guide
Leave approximately 1/8" overlap on all edges for probable shrinkage over time
Start at a corner and peel off the backing paper to apply
Smooth from center out to help eliminate bubbles of air

CLEANING AND MAINTENANCE

Clean by simply wiping the surface with a damp cloth and mild soap if necessary

REMOVAL

Peel adhesive liner off of covered surface piece by piece
To remove excess adhesive apply a citrus-based solvent to the surface where the contact paper was applied
Allow the solvent to sit for approximately 5 minutes to dissolve the remaining adhesive
Scrub the surface with a sponge to remove adhesive residue
Rinse the sponge in clean water and wipe the surface to remove any excess solvent
Leave doors and drawers open to allow the interior of cabinets and drawers to dry

To remove stubborn pieces, first heat the surface to loosen the adhesive's grip (e.g. blow dryer on low setting) then follow the steps listed above.

