

SOLUTIONS HOW TO INSTALL BATHTUB STRIPS & TUB TATTOOS

Unlike our <u>non-slip bath mats</u>, which use suction cups, our <u>bathtub strips</u>, appliques and Tub Tattoos use a strong adhesive in order to provide reliable slip-resistance in the tub or shower. Please review these instructions carefully to ensure maximum contact between the adhesive and the surface.

1. CLEAN & PREPARE THE SURFACE

Ensure <u>all</u> residue and mineral build-up are removed from the target surface by completing these steps in order:

- Clean the surface with your regular, household cleaner.
- Dry completely.
- Apply rubbing alcohol to desired surface.
- Dry completely. You're ready to install!

2. INSTALLATION PROCEDURE

- Pick your desired layout.
- Peel the backing off the first Tub Tattoo.
- Press tub tread against surface working your way outward, eliminating any air bubbles.
- Wait 4 hours minimum before getting the <u>tub appliques</u> wet. If possible, we recommend waiting 24 hours.

Questions on your Safety Treads? Visit <u>www.slipxsolutions.com</u> or call 1-800-968-0104.

