

W/O WESTIN OUTDOOR







Assembly Instructions

Model: 2001

CHAIR PARTS INCLUDED:

- (A) Seat-1 unit
- (B) Backrest-1 unit
- (C) Armrest-2 units
- (D) Front leg-2 units
- (G) Front brace-1 unit
- (F) Seat brace-1 unit
- (G) Gliders-2 units

HARDWARE PARTS INCLUDED:

| Qty. | Description |
|------|--|
| 4 |  1.6" Screw |
| 8 |  2.2" Carriage bolt |
| 2 |  1.6" Bolt |
| 2 |  3.2" Carriage bolt |
| 10 |  Lock nut |
| 10 |  Washer |
| 1 | Allen Key, Wrench, Phillips head screwdriver |

STRUCTURE DIAGRAM:

